

SKYN CARE.co



5-IN-1 SHAVING SET

CONTENTS

Introduction	4
Getting to Know	5
Features	5
How to Guide	6
Keeping it Clean	9
Stay Powered	9
FAQs	10
Warnings	11
Here to Help	16

INTRODUCTION

Effortlessly achieve your style with the Skyncare.co 5-in-1 Grooming Set for face and body. This grooming set contains 5 interchangeable heads to create a quick, sharp and more efficient look across the body, face and hair - this grooming set is all you need.



GETTING TO KNOW YOUR 5-IN-1 GROOMING SET

NAME - 5-in-1 Grooming Set

MODEL NUMBER - LMS-MSS

POWER - 3V / 1.2W

TYPE OF BATTERY - 2 x AAA (Not included)

FEATURES

- For dry use/waterproof
- Battery operated (2 x AAA, Not included)
- Storage base
- 5 interchangeable heads
- Fully washable

HOW TO GUIDE

LET'S BEGIN

CHANGING THE INTERCHANGEABLE HEADS

1. Select the head you wish to use and make sure the appliance is turned off before you start removing the current head
2. To remove the head, rotate it anti-clockwise until the alignment indicator on the head is aligned with the right alignment indicator on the appliance body, and pull the head upwards to remove it. See picture below



3. To install the head, align the alignment indicator on the head with the right alignment indicator on the appliance body and rotate it clockwise until it locks into position. See picture below



USING THE APPLIANCE

TRIMMING HEAD - Suitable to trim large areas such as head hair and thick body hair

1. Attach the trimming head as per instructions above
2. Slide the power switch upwards to turn the appliance on and place the trimming head lightly on the area you want to trim and move it against hair growth to trim



SHAVING HEAD - Suitable to shave beard and/or moustache

1. Attach the trimming head as per instructions above
2. Slide the power switch upwards to turn the appliance on
3. Place the shaving head close to the skin at a 90° angle and move the shaving head slowly and smoothly



SIDEBURNS TRIMMING HEAD - Suitable to trim sideburns and hair around ears

1. Attach the trimming head as per instructions above
2. Slide the power switch upwards to turn the appliance on
3. With the trimming head parallel to the skin, gently touch the hairs
4. You can also use the flat part of the trimming head as support



EYEBROWS TRIMMING HEAD - Suitable to trim eyebrows and hairline

1. Attach the trimming head as per instructions above
2. Slide the power switch upwards to turn the appliance on
3. Use the eyebrows trimming head from the outside to inside, against hair growth to trim



DETAIL TRIMMING HEAD - Suitable to trim nasal hairs and detailing

1. Attach the trimming head as per instructions above
2. Slide the power switch upwards to turn the appliance on
3. For nasal hair, gently place the trimmer into the nose and move the head slowly
4. For hair detailing the trimming head should lightly touch head hairs, you can then move the appliance slowly and smoothly to trim




KEEPING IT CLEAN

1. Make sure the appliance is turned off before you start cleaning it
2. Remove the attachment head and clean with the brush included
3. Rinse thoroughly with water
4. Pat dry and store away

STAY POWERED

1. With the device turned off, remove the protective cap
2. Hold the device in one hand and with the other remove the battery cover, as illustrated below
3. Insert 2 x AAA batteries (not included)
4. Replace the battery cover



5. Batteries contain substances harmful to our environment. Do not dispose of the appliance and the batteries in the normal household waste, please hand them over to an official recycling point for environmental protection

FAQS

Why is my device not working?

Check the batteries inserted are new and inserted correctly. Use the guide included in this manual to assist.

Can I use this if I have sensitive skin or a skin condition?

Whilst the product is very gentle, if you have a pre-existing condition, we do recommend you consult your doctor or dermatologist before using.

Why isn't my device turning on?

This could be the battery being low or out of power. Try replacing the battery and ensuring you follow the battery direction on the casing.

Why is my device making an abnormal noise?

Check the head is installed correctly as guided.

WARNINGS

- Keep away from children
- Do not use the appliance on open cuts or wounds, inflammation, chapped or swollen skin, severe skin diseases or conditions or allergies
- Check the appliance for damages before you start using it. Do not use the appliance if you identify any damage to prevent injuries.
- This appliance has different attachment heads, before use, select the attachment head you want to use to prevent accidents or using the wrong attachment for the area
- If you feel discomfort when using the appliance, stop using it and consult your doctor
- Do not attempt to modify, disassemble (except the removable parts), or repair the appliance by yourself to prevent accidents
- Do not share the same appliance with others
- Regularly clean the appliance to extend its lifetime
- This appliance is battery-operated. If you do not use the appliance for a long time, remove the batteries
- The surface of the appliance can be washed under tap water (DO NOT immerse the appliance in water) and dry it with a dry cloth.
- The removable heads should be cleaned with the included cleaning brush and then rinsed with water
- Do not use lubricants, detergents, polishing agents or air fresheners on the appliance
- Do not use towels, paper towels, or wire ball sponges to clean the trimmer or shaver blade

WAARSCHUWINGEN

- Uit de buurt van kinderen houden
- Gebruik het apparaat niet op open snijwonden of wonden, ontstekingen, schrale of gezwollen huid, ernstige huidziekten of -aandoeningen of allergieën.
- Controleer het apparaat op beschadigingen voordat u het in gebruik neemt. Gebruik het apparaat niet als u schade vaststelt om letsel te voorkomen.
- Dit apparaat heeft verschillende opzetstukken, kies vóór gebruik het opzetstuk dat u wilt gebruiken om ongelukken of het gebruik van het verkeerde opzetstuk voor het gebied te voorkomen.
- Als u ongemak voelt bij het gebruik van het toestel, stop dan met het gebruik en raadpleeg uw arts.
- Probeer het apparaat niet zelf te wijzigen, te demonteren (behalve de verwijderbare onderdelen) of te repareren om ongelukken te voorkomen.
- Deel niet hetzelfde apparaat met anderen
- Maak het apparaat regelmatig schoon om de levensduur te verlengen
- Dit apparaat werkt op batterijen. Verwijder de batterijen als u het apparaat lange tijd niet gebruikt.
- Het oppervlak van het apparaat kan worden gewassen onder kraanwater (dompel het apparaat NIET onder in water) en droog het af met een droge doek.
- De verwijderbare koppen moeten worden gereinigd met de meegeleverde reinigingsborstel en vervolgens met water worden afgespoeld.
- Gebruik geen smeermiddelen, schoonmaakmiddelen, poetsmiddelen of luchtverfrissers op het apparaat.
- Gebruik geen handdoeken, papieren handdoeken of draadkogelsponsjes om de trimmer of het scheerblad te reinigen.

WARNUNGEN

- Von Kindern fernhalten
- Verwenden Sie das Gerät nicht bei offenen Schnitten oder Wunden, Entzündungen, rissiger oder geschwollener Haut, schweren Hautkrankheiten oder -zuständen oder Allergien
- Überprüfen Sie das Gerät auf Schäden, bevor Sie es in Betrieb nehmen. Verwenden Sie das Gerät nicht, wenn Sie einen Schaden feststellen, um Verletzungen zu vermeiden.
- Dieses Gerät verfügt über verschiedene Aufsatzköpfe. Wählen Sie vor dem Gebrauch den gewünschten Aufsatzkopf aus, um Unfälle oder die Verwendung des falschen Aufsatzes für den jeweiligen Bereich zu vermeiden.
- Wenn Sie bei der Verwendung des Geräts Beschwerden verspüren, brechen Sie die Verwendung ab und wenden Sie sich an Ihren Arzt.
- Versuchen Sie nicht, das Gerät selbst zu modifizieren, zu zerlegen (außer den abnehmbaren Teilen) oder zu reparieren, um Unfälle zu vermeiden.
- Teilen Sie nicht dasselbe Gerät mit anderen
- Regelmäßige Reinigung des Geräts verlängert seine Lebensdauer
- Dieses Gerät ist batteriebetrieben. Wenn Sie das Gerät über einen längeren Zeitraum nicht benutzen, nehmen Sie die Batterien heraus
- Die Oberfläche des Geräts kann unter Leitungswasser gereinigt werden (das Gerät NICHT in Wasser tauchen) und mit einem trockenen Tuch abtrocknen.
- Die abnehmbaren Köpfe sollten mit der mitgelieferten Reinigungsbürste gereinigt und anschließend mit Wasser abgespült werden
- Verwenden Sie keine Schmiermittel, Reinigungsmittel, Poliermittel oder Lufterfrischer für das Gerät.
- Verwenden Sie keine Handtücher, Papiertücher oder Drahtkugelschwämme, um den Trimmer oder die Rasierklinge zu reinigen.


OSTRZEŻENIA

- Trzymać z dala od dzieci
- Nie należy stosować urządzenia na otwarte skaleczenia lub rany, stany zapalne, spierzchniętą lub opuchniętą skórę, poważne choroby lub schorzenia skóry lub alergię
- Sprawdź urządzenie pod kątem uszkodzeń przed rozpoczęciem użytkowania. Nie używaj urządzenia, jeśli stwierdzisz jakiegokolwiek uszkodzenia, aby zapobiec obrażeniom.
- Urządzenie posiada różne głowice, przed użyciem należy wybrać głowicę, która ma być użyta, aby zapobiec wypadkom lub użyciu niewłaściwej głowicy do danego obszaru.
- W przypadku odczuwania dyskomfortu podczas używania urządzenia, należy je przerwać i skonsultować się z lekarzem
- Nie należy podejmować prób samodzielnego modyfikowania, demontażu (z wyjątkiem zdejmowanych części) lub naprawy urządzenia, aby zapobiec wypadkom
- Nie należy udostępniać tego samego urządzenia innym osobom]
- Regularnie czyść urządzenie, aby przedłużyć jego żywotność
- To urządzenie jest zasilane bateriami. Jeśli urządzenie nie będzie używane przez dłuższy czas, należy wyjąć baterie.
- Powierzchnię urządzenia można umyć pod wodą z kranu (NIE zanurzać urządzenia w wodzie) i osuszyć suchą szmatką.
- Zdejmowane głowice należy czyścić za pomocą dołączonej szczotki czyszczącej, a następnie spłukać wodą
- Nie używaj na urządzeniu smarów, detergentów, środków polerujących ani odświeżaczy powietrza
- Do czyszczenia ostrzy trymera lub golarki nie należy używać ręczników, ręczników papierowych ani gąbek z drucianymi kulkami.


HERE TO HELP

 hello@skyncare.co


 www.skyncare.co

 Skyncare.co
(Kinetik Medical Devices Ltd)
Unit 3, Perrywood Business Park
Honeycrook Lane
Salfords, Redhill, RH1 5DZ
UK

 Symbol for “Manufacture Date”

 Symbol for “Environment Protection” - Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice

 Symbol for “Complies with EU Requirements”

 Symbol for “Complies with UK Requirements”

 Follow this instruction manual for your safety

 Symbol for “No use in bathroom”

 Model Reference

Made in China
LMS-MSS